


CG260B BRUSH CUTTER






Pakningssæt

Gasket assy :



860261

CG260B BRUSH CUTTER

SER. NO.	PART NO.	PART NAME	QTY.	SER. NO.	PART NO.	PART NAME	QTY.	SER. NO.	PART NO.	PART NAME	QTY.	SER. NO.	PART NO.	PART NAME	QTY.
1	CG415.3	GEAR CASE ASS'Y	1	21	GB97.1	WASHER 5	4	41	CG260.1-1	CLUTCH CASE	1	61	CG260.4	HARNESS ASS'Y	1
2	GB893.2	STOP RING 26	1	22	GB93	WASHER 5	4	42	CG305F.14-2	ABSORBER	1	62	CG305-5	SHORT GROUND WIRE	1
3	GB894.1	STOP RING 10	1	23	GB70	SCREW M5×25	2	43	GB70	SCREW M5×25	2	63	CG415D.2.1.2-1	STOP BASE	1
4	GB/T276	BEARING 6000-2RS/P5	2	24	BG415-2	BLADE	1	44	CG305F.14-4	CAP A	1	64	CG415D.2.1.2-2	SLIDING SUPPORT	1
5	CG415D.6-4	PINION	1	25	CG260.3	CLAMP ASS'Y	1	45	CG305F.14-3	CAP B	1	65	CG415D.2.1.2-3	LEAF SPRING	1
6	CG415.3-1	STEEL PLATE CAP	1	26	CG260.3.1	HARNESS CLAMP	1	46	GB70	SCREW M6×20	4	66	GB845	SCREW ST2.9×8	3
7	CG415D.6-1	GEAR CASE WASHER	2	27	CG260.3-1	CLAMP	1	47	GB93	WASHER 6	4	67	CG415D.2.1-8	RIGHT LEAF SPRING	1
8	GB29.2	BOLT M6×12	2	28	GB70	SCREW M5×20	1	48	GB97.1	WASHER 6	4	68	CG415D.2.1-5	CONTROL BASE	1
9	GB97.1	WASHER 6	2	29	GB889	NUT M5	1	49	CG260B.1.1.1	CABLE ASS'Y	1	69	CG415D.2.1-6	CONTROL HANDLE	1
10	CG305.12.4-4	GEAR CASE	1	30	BG-328.9.4-5	RUBBER COVER	5	50	CG260B-1	TUBE	1	70	GB896	STOP RING 6	1
11	GB/T276	BEARING 6000/P5	1	31	BG-328.9.4-4	OIL-BEARING	5	51	CG260B.1.1.2	STOP WIRE COMP.	1	71	CG415D.2.1-2	SPRING	1
12	BG-328.9.5-2	GEAR CASE	1	32	CG415D.4-1	DRIVE SHAFT	1	52	CG260B.1.1	THROTTLE LEVER ASS'Y	1	72	CG415D.2.1-1	LOCKING PIN	1
13	CG305F.1-1	GEAR SAFE	1	33	CG260A.2-1	ALUMINUM PIPE	1	53	CG415D.2-3	GRIP, RIGHT	1	73	CG415D.2.1-3	SPRING	1
14	GB/T276	BEARING 6002-2RS/P5	1	34	CG305F.7.1	SAFETY GUARD ASS'Y	1	54	CG415D.2-2	HANDLE	2	74	CG415D.2.1-4	LOCKER	1
15	GB893.2	STOP RING 32	1	35	GB9074.4	SCREW M5×12	4	55	GB9074.13	BOLT M5×25	6	75	GB889	NUT M5	1
16	BG305.12.4-5	CUTTER HOLDER	1	36	CG260A.1	CLUTCH COMP.	1	56	CG415D.3-1	GRIP, LEFT	1	76	GB818	SCREW M5×25	1
17	CG305F.1-3	CUTTER HOLDER CAP.	1	37	CG260A.1.1	CLUTCH DRUM COMP.	1	57	CG415D-1	CAP, UPPER	1	77	CG415D.2.1-7	LEFT LEAF SPRING	1
18	GB862.1	WASHER 10	1	38	GB893.1	STOP RING 35	1	58	CG415-1	BRACKET	1				
19	CG305F.1-4	CUTTER FIXING NUT/L.H.T	1	39	GB/T276	BEARING 6202-2RS/P5	2	59	CG415-2	CAP, LOWER	1				
20	GB91	PIN 2×16	1	40	GB894.1	STOP RING 15	1	60	BG415-1	WIRE CLAMP BAND	1				



23




Trimmerhead / Snørrehoved

23	CG305F10	Cpl.
25	CG305F.8.1	
26	CG305F.8-4	
27	CG305F.8-5	
28	CG305F.8-3	
29	5015-00	
30	CG305F.8-1	
31	CG305F.8-2	

Guard / Skærm

43	GB889	
62	CG305F.11	Cpl.
63	CG305F.11-2	
64	GB9074.4	
65	CG305F.11-1	
66	CG305F-7	
67	GB9074.3	

FIG. 1 1E34F GASOLINE ENGINE



1E34F GASOLINE ENGINE

SER. NO.	PART NO.	PART NAME	QTY.	SER. NO.	PART NO.	PART NAME	QTY.	SER. NO.	PART NO.	PART NAME	QTY.
1	1E34F. 1. 2	SCREW	1	29	1E34F-4	GUIDE PLATE	1	58	1E34F-3	GASKET	1
2	1E34F. 1-4	CLEANER OUTSIDE COVER	1	30	1E34F. 7-2	CRANK CASE GASKET	1	59	1E34F. 2	MUFFLER COMP.	1
3	1E34F. 1-1	CLEANER ELEMENT	1	31	1E36F. 2	OIL SEAL	2	60	1E34F-14	BOLT	2
4	GB9074. 4	SCREW M5×55	2	32	GB276	BALL BEARING 6001/P5	2	61	GB96	WASHER 5	3
5	1E34F. 1. 1	CLEANER INSIDE COVER	1	33	1E40FP-3Z. 3-1	KEY	1	62	GB6187	NUT M5	2
6	GB845	SCREW ST4. 2×12-F-H	1	34	1E34F. 6. 1	CRANK SHAFT COMP.	1	63	1E34F-8	CYLINDER	1
7	1E34F. 1-3	CHOKE	1	35	1E34F. 7-3	REAR HALF CRANK CASE	1	64	1E34F-9	CYLINDER WASHER	1
8	1E34F. 1-2	CHOKE HANDLE	1	36	1E34F. 8. 1	STARTER PULLEY ASS'Y	1	65	1E34F. 6-5	PISTON RING	2
9	WYJ 244	CARBURETOR	1	37	1E34F. 8-2	STARTER PAWL SPRING	1	66	1E34F. 6-6	PISTON	1
10	1E34F-1	GASKET	1	38	1E34F. 8-1	STARTER PAWL	1	67	1E34F. 6-1	STOP RING	2
11	GB9074. 4	SCREW M5×20	6	39	GB9074. 6	SCREW M5×10	1	68	1E34F. 6-3	PISTON PIN	1
12	1E34F. 4	INLET MANIFOLD	1	40	1E34F. 11-1	RECOIL SPRING	1	69	1E34F. 6-4	NEEDLE BEARING	1
13	1E34F-2	CYLINDER WASHER	1	41	1E34F. 11-2	STARTER ROPE REEL	1	70	1E34F. 6-2	PISTON PIN CIRCLET	2
14	GB119	ANNUL B3×10	4	42	1E34F. 11. 1	RECOIL STARTER BODY	1	71	EB-415. 4. 1-1	FUEL TANK LID	1
15	GB9074. 4	SCREW M4×16	9	43	1E34F. 11. 1-1	ROPE GUIDE	1	72	EB-415. 4. 1. 1-1	AIRINLET MOUTH	1
16	1E34F-5	FAN COVER	1	44	1E34F. 11-3	ROPE	1	73	EB-415. 4. 1. 1-3	FRAME	1
17	1E34F-12	CLUTCH STEP SCREW	2	45	1E36F. 1-1	STARTER HANDLE	1	74	EB-415. 4. 1. 1-2	GASKET	1
18	1E34F-13	WASHER	2	46	1E36F. 1-5	GASKET	1	75	1E34F. 9. 2-2	OUTLET FUEL PIPE	1
19	1E34F. 10. 1	CLUTCH SHOE COMP.	2	47	GB9074. 4	SCREW M5×14	1	76	1E34F. 9. 2-1	INLET FUEL PIPE	1
20	1E34F-11	WASHER	2	48	1E34F-6	COVER	1	77	1E36FF. 8. 1-1	PRIMARY CORD GROMMET	1
21	1E34F. 10-1	CLUTCH SPRING	1	49	1E34F. 3	COVER	1	78	1E34F. 9. 2-3	CLEANER	1
22	GB6171	NUT M8×1	1	50	GB9074. 4	SCREW M4×12	1	79	1E34F. 9. 1	FUEL TANK	1
23	GB97. 1	WASHER 8	1	51	1E34F. 5-2	PLUG CAP	1	80	GB9074. 3	SCREW M5×16	1
24	QQ-1	STOP CORD COMP.	1	52	1E40F-3A. 8-2	CLICK SPRING	1	81	GB9074. 4	SCREW M5×16	2
25	1E34F. 5-1	PRIMARY CORD GROMMET	1	53	1E34F. 5-3	PLUG COVER	1	82	1E34F6	STARTER PULLEY ASS'S	1
26	UK-08922	MAGNETO STATOR	1	54	RCJ6Y(CHAMPION)	SPARK PLUG	1	83	1E34F8	STARTER	1
26A	UK-08922A	MAGNETO ROTOR	1	55	GB70	SCREW M5×20	4	84	1E36FF-11	FLASH PAN	1
27	GB9074. 4	SCREW M5×25	4	56	GB93	WASHER 5	4	85	11EB-41541	FUEL CAP, ASSY	1
28	1E34F. 7-1	FRONT HALF CRANK CASE	1	57	GB848	WASHER 5	4				