



**KOMATSU
ZENOAH**

G300AV/G300AVS

PARTS LIST

CHAIN SAWS

**G300AV
G300AVS**

KOMATSU ZENOAH CO.

2-142-1, Sakuragaoka, Higashiyamato.

Tokyo 189 Japan

Phone 0425-61-2141 Telex 2842-243

Form.No.22B-1002-06010-00

Fig. A




Fig. No.	Parts Number		Description	Q'ty /Unit	Remarks
	Q300AV	Q300AVS			
A-1	2630-12110		CYLINDER	1	
2	2630-15100		MUFFLER ASS'Y	1	
3	2630-15110		BASE	1	
4	2630-15120		COVER	1	
5	2630-15130		BAFFLE	1	
6	2630-15210		GASKET	1	
7	3330-15220		BOLT	2	
8	2630-21111		CRANCKCASE	1	
9	01252-30630		BOLT	4	
10	2630-22100		VALVE ASS'Y	1	
11	2630-22210		GASKET	1	
12	3330-14120		GASKET	1	
13	2640-31100		ENGINE CASE COMP.	1	
15	2631-31201		FUEL PIPE ASS'Y	1	
16	1492-85410		PIPE	1	
17	1750-85300		FILTER ASS'Y	1	
18	1260-85460		CLIP	2	
19	3350-34320		ELBOW	1	
20	2631-31250		GROMMET	1	
21	3317-86100		BREATHER ASS'Y	1	
22	2630-31300		OIL PIPE ASS'Y	1	
23	1492-85410		PIPE	1	
24	2630-31320		GROMMET	1	
25	2630-31330		JOINT	1	
26	2630-31350		FILTER	1	
27	1492-85410		PIPE	1	
28	3370-31210		PIN	1	
29	2630-31510		VALVE ASS'Y	1	
30	2630-31610		SEAL	1	
31	2630-31650		CAP	1	
32	3370-31710		PIPE	4	
33	2630-31750		SCREW	4	
34	2630-31800		CAP ASS'Y	2	
35	2630-31820		GASKET	2	
36	2630-31830		STOPPER	2	
37	2630-31840		CLIP	2	
38	2630-82650		SCREW	2	
39	2630-31910		COVER	1	
40	2630-31960		SCREW	2	
41	2641-32100		FRONT HANDLE ASS'Y	1	
42	2641-32110		HANDLE	1	
43	2630-32120		JOINT (A)	1	
44	2630-32150		STOPPER	1	
45	2630-32170		SCREW	1	
46	2630-32170		SCREW	1	
47	2630-32610		SCREW	2	
48	2640-33100		REAR HANDLE COMP.	1	
49	3330-33250		STOPPER	1	
50	3310-33262		SPRING	1	
51	3310-33271		KNOB	1	
52	2640-33310		THROTTLE LEVER	1	
53	3356-33321		SPRING	1	
54	04025-00524		SPRING PIN	1	
55	3356-33350		ARM	1	
56	2640-33210		LINK	1	
57	2640-33250		ROD	1	
58	04025-00524		SPRING PIN	1	
59	2640-33410		COVER	1	
60	2630-31950		SCREW	1	
61	2640-33450		GUARD	1	

Fig. No.	Parts Number		Description	Q'ty /Unit	Remarks
	Q300AV	Q300AVS			
A-82	3317-33621		PIN	1	
83	3310-33631		SPRING	1	
84	0308-00040		RING	1	
85	2640-33510		JOINT (B)	1	
86	2640-33530		BOLT	1	
87	2630-33610		SCREW	2	
88	2640-33710		JOINT (C)	2	
89	2640-33530		BOLT	2	
70	2630-75510		SCREW	2	
71	2640-33810		JOINT (D)	1	
72	0263-80612		SCREW	1	
73	2630-75510		SCREW	1	
74	2630-41110		PISTON	1	
75	2630-41210		RING	1	
76	2630-41310		PIN	1	
77	1260-41320		SNAP RING	2	
78	1101-41331		BEARING	1	
79	2630-41340		WASHER	2	
80	2630-42001		CRANKSHAFT COMP.	1	
81	06030-06201		BEARING	2	
82	2630-43150		OIL SEAL	1	
83	04066-03212		SNAP RING	1	
84	1100-21210		OIL SEAL	1	
85	1650-43230		NUT	1	
86	2631-51110		CLUTCH DRUM	1	
87	3310-51310		BEARING	1	
88	2630-51200		CLUTCH ASS'Y	1	
89	2630-51210		SHOE	2	
90	3330-51220		BOSS	1	
91	2630-51230		SPRING	2	
92	2630-51410		SPACER	1	
93	2642-54000		CHAIN BRAKE ASS'Y	1	
94	2640-53100	2642-54100	COVER COMPLETE	1	
95	2640-53120	2642-54120	LABEL	1	
96	2632-54210		ARM (A)	1	
97	3330-96221		ARM (B)	1	
98	3330-96231		SPRING	1	
99	3330-96251		BAND	1	
100	3330-96260		ROLLER	1	
101	3330-96311		GUARD	1	
102	2632-54410		PLATE	1	
103	2630-31750		SCREW	1	
104	2630-31950		SCREW	1	
105	3350-53410		NUT	1	
106	2630-53310		PLATE	1	
107	1600-33130		SCREW	1	
108	0263-20535		SCREW	1	
109	3310-53320		NUT (A)	1	
110	2630-53410		CATCHER	1	
111	2630-32170		SCREW	1	
112	2630-55100		OIL PUMP ASS'Y	1	
113	2630-55180		GEAR	1	
114	0261-00416		SCREW	2	
115	2630-55210		PLATE	1	
116	2630-55250		SEAL	1	
117	2630-55310		COVER	1	
118	2630-31950		SCREW	2	
119	2631-71110		MODULE	1	
120	2631-71200		ROTOR ASS'Y	1	
121	2630-71220		PAWL	2	

Fig. No.	Parts Number		Description	Q'ty /Unit	Remarks
	Q300AV	Q300AVS			
A-122	2630-71230		SPRING	2	
123	0308-00040		SNAP RING	2	
124	1260-71260		SPACER	2	
125	0263-30425		SCREW	2	
126	3330-71410		SPARK PLUG	1	
127	1400-72111		CAP	1	
128	1400-72121		SPRING	1	
129	2630-72210		TUBE	1	
130	2630-72600		SWITCH ASS'Y	1	
131	2630-72610		LEAD	1	
132	2631-75000		STARTER ASS'Y	1	
133	2631-75100		CASE COMP.	1	
134	3330-75121		GUIDE	1	
135	2631-75130		LABEL	1	
136	2630-75210		REEL	1	
137	1260-75151		ROPE	1	
138	3330-75420		KNOB	1	
139	3330-75201		HOLDER COMP.	1	
140	2630-75410		WASHER	1	
141	2630-75510		SCREW	1	
142	2630-31950		SCREW	4	
143	2631-81000		CARBURETOR ASS'Y	1	
144	3310-82110		WASHER	1	
145	2630-82120		CHOKE PLATE	1	
146	2630-82140		SCREW	2	
147	2640-82150		THROTTLE ROD	1	
148	2630-82160		GROMMET	1	
149	2630-82210		GROMMET (A)	1	
150	2630-82220		GROMMET (B)	1	
151	2630-82310		CHOKE ROD	1	
152	3320-33310		GROMMET	1	
153	2631-82550		CAP	1	
154	2630-83100		CLEANER COVER SUB ASS'Y	1	
155	2630-83120		KNOB	1	
156	0308-00040		SNAP RING	1	
157	2630-83610		CLEANER	1	
158	2630-83610		ELEMENT	1	
159	2641-33610	2642-33610	LABEL	1	
160	0304-02040		RIVET	4	

Fig. B CARBURETOR




Fig. C ACCESSORIES




Fig. D SPECIAL TOOLS




Fig. No.	Parts Number		Description	Q'ty/Unit	Remarks
	G300AV	G300AVS			
B-1	2631-81120		PUMP COVER	1	
2	2631-81130		SCREW	1	
3	2631-81160		SPRING	2	
4	2631-81170		SLOW ADJUST SCREW	1	
5	2631-81230		METERING LEVER	1	
6	2631-81240		SCREW	1	
7	2631-81250		PIN	1	
8	2631-81270		SPRING	1	
9	2631-81280		COVER	1	
10	2631-81310		NEEDLE VALVE	1	
11	2631-81330		MAIN ADJUST SCREW	1	
12	2631-81340		THROTTLE VALVE	1	
13	2631-81350		SCREW	2	
14	2631-81360		SCREW	1	
15	2631-81370		SHAFT ASS'Y	1	
16	2631-81380		STRAINER	1	
17	2631-81390		COLLAR	1	
18	2631-81410		SPRING	1	
19	2631-81420		PLUG	1	
20	2631-81440		LEVER	1	
21	2631-81450		SCREW	1	
22	2631-81460		FRICTION PIECE	1	
23	2631-81470		THROTTLE ADJUST SCREW	1	
24	2631-06010		GASKET KIT	1	
25	2631-06020		DIAPHRAGM KIT		

Fig. No.	Parts Number		Description	Q'ty/Unit	Remarks
	G300AV	G300AVS			
C-1	3606-00001		BAR SET	1	
2	3606-52111		BAR 12"	1	
3	3600-52210		CHAIN	1	
4	3310-97112		PROTECTOR	1	
5	3320-91140		WRENCH	1	

Fig. No.	Parts Number		Description	Q'ty/Unit	Remarks
	G300AV	G300AVS			
D-1	3320-96410		STOPPER	—	OP.
2	3330-97110		WRENCH	—	OP.
3	3330-97310		GAUGE	—	OP.
4	09007-00425		WRENCH	—	OP.